


RB443T

EXPLODED
VIEW AND SPARE PARTS LIST

DESPIECE DE LA MAQUINA Y LISTA
DE RECAMBIOS

SCHEMA ECLATE ET LISTE DES
PIECES DE RECHANGE



ToolModel	PartNo	PartCode	Description
RB443T	1	RB71027	ARM A ASSY
RB443T	2	BB40481	BOLT 3X5
RB443T	3	AA71408	SCREW 3X3
RB443T	4	RB13145	WIRE GUIDE BASE
RB443T	5	RB81422	ARM A UNIT
RB443T	6	BB41714	BOLT 3X5
RB443T	7	RB12636	WIRE GUIDE LEVER
RB443T	8	KK29117	COMPRESSION SPRING 9117
RB443T	9	RB70620	WIRE GUIDE UNIT
RB443T	10	FF41865	STEP PIN 1865
RB443T	11	JJ10113	E-RING 2.5
RB443T	12	BB40420	BOLT 4X16
RB443T	13	FF52115	HOLLOW PIN 2115
RB443T	14	EE39861	WASHER 4.3X9X1
RB443T	15	RB13161	FEEDING GEAR A
RB443T	16	RB13160	SHAFT COLLAR
RB443T	17	RB71035	GEAR A UNIT
RB443T	18	RB71036	FEEDING MOTOR
RB443T	19	JJ10514	E-RING 3
RB443T	20	RB70625	FEEDING GEAR B UNIT
RB443T	21	RB12964	FEEDING GEAR SHAFT B
RB443T	22	RB71039	FEEDING GEAR BASE UNIT
RB443T	23	RB12963	SPRING BASE
RB443T	24	BB40849	BOLT 4X6
RB443T	25	RB81424	FEEDING GEAR BASE ASSY
RB443T	26	BB40824	BOLT 3X6
RB443T	27	RB71038	WIRE GUIDE C UNIT
RB443T	28	RB12866	RELEASE LEVER A
RB443T	29	FF41877	STEP PIN 1877
RB443T	30	RB81334	RELEASE LEVER A ASSY
RB443T	31	BB41715	BOLT 4X18
RB443T	32	EE11103	SPRING WASHER 2-4
RB443T	33	EE39825	WASHER 4.5X7.4X0.8
RB443T	34	FF52118	HOLLOW PIN 2118
RB443T	35	CC42512	HEX NUT 1A M4
RB443T	36	FF41867	STEP PIN 1867
RB443T	37	KK29119	COMPRESSION SPRING 9119
RB443T	38	JJ10510	E-RING 2.3
RB443T	39	RB12657	RELEASE LEVER B
RB443T	40	FF41868	STEP PIN 1868
RB443T	41	RB81423	FEED ASSY
RB443T	42	RB13134	HOOK L
RB443T	43	RB12853	CARBIDE PIN 2.5X14.8
RB443T	44	RB12616	SLEEVE COVER
RB443T	45	FF21267	SPRING PIN 2X8
RB443T	46	RB12610	HOOK R
RB443T	47	FF31718	PARALELL PIN 1718
RB443T	48	RB13135	SLEEVE A
RB443T	49	RB13138	KEY
RB443T	50	RB12611	CENTER HOOK
RB443T	51	RB12713	KEY B

ToolModel	PartNo	PartCode	Description
RB443T	52	RB12612	SLEEVE GUIDE
RB443T	53	RB12615	SLEEVE B
RB443T	54	FF21234	SPRING PIN 3X12
RB443T	55	RB13136	CUTTER RING
RB443T	56	RB12618	CUTTER RING GUIDE
RB443T	57	JJ21606	C-RING 15
RB443T	58	JJ80901	C-RING 11
RB443T	59	RB12714	BUMPER GUIDE
RB443T	60	RB12619	BUMPER
RB443T	61	EE39876	WASHER 11.1X23.4X2C
RB443T	62	JJ21019	C-RING 17
RB443T	63	RB13139	BEARING COLLAR
RB443T	64	LL11756	BEARING 6803ZZ
RB443T	65	JJ21603	C-RING 20
RB443T	66	RB13137	INTERNAL GEAR
RB443T	67	RB12783	RING
RB443T	68	RB12720	D RING
RB443T	69	RB71023	TIP AXIS A UNIT
RB443T	70	RB12622	PLANETARY GEAR
RB443T	71	RB71025	SUN GEAR UNIT
RB443T	72	RB12623	WASHER, TWIST AXIS
RB443T	73	RB71026	TWISTING MOTOR
RB443T	74	RB71022	TWIST ASSY
RB443T	75	BB40425	BOLT 3X10
RB443T	76	RB71090	MOTOR COVER UNIT (443USA)
RB443T	77	RB71043	CONNECTOR COVER UNIT
RB443T	78	RB13173	TERMINAL COVER
RB443T	79	BB41706	BOLT 4X10
RB443T	80	RB12634	COVER L
RB443T	81	FF51817	HOLLOW PIN 1817
RB443T	82	FF51710	HOLLOW PIN 1710
RB443T	83	CC49308	HEX NUT M4
RB443T	84	CC42510	HEX NUT M3
RB443T	85	RB12119	SLOTTED HEX NUT M4
RB443T	86	CC49508	LOCKING HEX NUT M5
RB443T	87	FF51714	HOLLOW PIN 1714
RB443T	88	RB13174	COLLAR NUT M3
RB443T	89	RB81425	FRAME L ASSY
RB443T	90	EE32104	WASHER 2-3
RB443T	91	BB40404	BOLT 5X16
RB443T	92	RB13172	HARNESS COVER
RB443T	93	AA05952	SCREW 2.6X10
RB443T	94	RB81421	MAIN CIRCUIT BOARD UNIT
RB443T	95	AA04503	SCREW 2.6X10(F)
RB443T	96	RB71056	DIAL CIRCUIT BOARD
RB443T	97	AA05723	SCREW 2X8
RB443T	98	RB13196	RUBBER COVER CASE
RB443T	99	RB13195	RUBBER COVER
RB443T	100	RB13194	LOADING ASSIST BUTTON CASE
RB443T	101	RB13187	MAIN SWITCH BASE
RB443T	102	KK29204	COMPRESSION SPRING 9204

ToolModel	PartNo	PartCode	Description
RB443T	103	RB13193	LOADING ASSIST BUTTON
RB443T	104	RB13206	LABEL, TORQUE DIAL
RB443T	105	RB13188	TORQUE DIAL
RB443T	106	ZS00034	MAIN SWITCH UNIT
RB443T	107	RB13190	SWITCH SEAL
RB443T	108	RB13192	LED LENS
RB443T	109	RB13191	SWITCH LOCK PLATE
RB443T	110	RB13208	DIAL LEAF SPRING
RB443T	111	RB13189	DIAL JOINT
RB443T	112	RB70626	POWER CORD ORANGE UNIT
RB443T	113	RB71021	MAIN SWITCH BASE ASSY
RB443T	114	RB71060	ELECTRODE UNIT
RB443T	115	RB70783	SWITCH BLOCK
RB443T	116	RB71048	WINDOW UNIT
RB443T	117	RB13123	COVER BOLT 3X10
RB443T	118	KK24191	COMPRESSION SPRING 4191
RB443T	119	RB13175	TRIGGER
RB443T	120	KK29205	COMPRESSION SPRING 9205
RB443T	121	RB13075	TRIGGER LOCK
RB443T	122	RB71073	SWITCH HARNESS UNIT
RB443T	123	RB12665	RELEASE BUTTON BASE
RB443T	124	KK33401	TORSION SPRING 3401
RB443T	125	RB12664	RELEASE STOPPER
RB443T	126	RB12662	RELEASE BUTTON
RB443T	127	RB13076	ALUMINUM LABEL
RB443T	128	RB12635	COVER R
RB443T	129	FF51642	HOLLOW PIN 1642
RB443T	130	RB13201	WARNING LABEL
RB443T	131	RB12661	BRAND PLATE
RB443T	132	RB71041	FRAME R ASSY (443T)
RB443T	133	BB40810	BOLT 3X16
RB443T	134	BB40716	BOLT 3X6
RB443T	135	BB40708	BOLT 5X25
RB443T	136	RB12725	SPONGE
RB443T	137	RB13178	MAGAZINE CAP
RB443T	138	RB71074	SENSOR CIRCUIT BOARD F UNIT
RB443T	139	RB12673	MAGAZINE STOPPER SHAFT
RB443T	140	KK24186	COMPRESSION SPRING 4186
RB443T	141	RB13204	WIRE LOADING LABEL
RB443T	142	RB13258	WIRE DIRECTION LABEL(OUT)
RB443T	143	FF51819	HOLLOW PIN 1819
RB443T	144	RB12672	MAGAZINE STOPPER
RB443T	145	FF21629	SPRING PIN 2X14
RB443T	146	RB13184	MAGAZINE ROLLER A
RB443T	147	RB13185	MAGAZINE ROLLER B
RB443T	148	RB13183	WIRE FEED SUPPORT
RB443T	149	BB40723	BOLT 3X40
RB443T	150	RB13227	WIRE DIRECTION LABEL(IN)
RB443T	151	RB13215	LOADING INSTRUCTION LABEL
RB443T	152	LL11012	BEARING F685HZZ
RB443T	153	RB81427	MAGAZINE SUB ASSY

ToolModel	PartNo	PartCode	Description
RB443T	154	JJ21605	C-RING 5
RB443T	155	RB12715	MAGAZINE PLATE
RB443T	156	RB13180	ROTARY SHAFT
RB443T	157	FF43419	STEP PIN 3419
RB443T	158	KK34098	TORSION SPRING 4098
RB443T	159	KK24204	COMPRESSION SPRING 4204
RB443T	160	EE39609	RUBBER WASHER 1.8X6X2
RB443T	161	RB13182	MAGAZINE COVER ROLLER
RB443T	162	LL62034	PLAIN BEARING
RB443T	163	RB13205	NOTICE LABEL
RB443T	164	RB13250	WIRE DIRECTION LABEL(COVER)
RB443T	165	EE39730	WASHER 3.2X8.5X0.5
RB443T	166	JJ10109	E-RING 2
RB443T	167	RB81429	MAGAZINE COVER SUB ASSY
RB443T	168	AA05560	SCREW 3X12
RB443T	169	JJ10107	E-RING 1.5
RB443T	170	EE39860	WASHER 5X2.6X1
RB443T	171	FF51713	HOLLOW PIN 1713
RB443T	172	FF31639	PARALELL PIN 1639
RB443T	173	KK34097	TORSION SPRING 4097
RB443T	174	RB12669	REEL PRESS
RB443T	175	RB71077	SENSOR CIRCUIT BOARD G UNIT
RB443T	176	AA31724	SCREW 2X8
RB443T	177	RB13179	MAGAZINE COVER CAP
RB443T	178	RB13203	443T LABEL
RB443T	179	RB81428	MAGAZINE COVER ASSY
RB443T	180	RB81426	MAGAZINE ASSY
RB443T	181	RB70624	CURL GUIDE A UNIT
RB443T	182	FF51712	HOLLOW PIN 1712
RB443T	183	KK34096	TORSION SPRING 4096
RB443T	184	RB13262	CURL GUIDE SHAFT(443T)
RB443T	185	RB12639	CURL GUIDE B
RB443T	186	RB71032	ARM B UNIT
RB443T	187	RB13149	FIXED CUTTER
RB443T	188	RB71031	WIRE GUIDE B UNIT
RB443T	189	RB12723	CON-ROD COVER GUIDE B
RB443T	190	RB12721	CUTTER CON-ROD COVER
RB443T	191	RB12722	CON-ROD COVER GUIDE A
RB443T	192	RB13148	CUTTER
RB443T	193	RB12724	CON-ROD COVER BASE
RB443T	194	RB12644	ARM C
RB443T	195	EE39858	WASHER 3.2X7X1
RB443T	196	KK33423	TORSION SPRING 3423
RB443T	197	RB71034	CUTTER CON-ROD UNIT
RB443T	198	RB13157	CUTTER CON-ROD FOLLOWER
RB443T	199	RB71030	ARM B ASSY
RB443T	200	FF51736	HOLLOW PIN 1736
RB443T	201	BB40811	BOLT 3X25
RB443T	202	RB13170	JAW B
RB443T	203	KK33249	TORSION SPRING 3249
RB443T	204	FF41864	STEP PIN 1864

ToolModel	PartNo	PartCode	Description
RB443T	205	RB13169	JAW A
RB443T	206	RB12625	JAW BASE
RB443T	207	RB71044	JAW BASE ASSY
RB443T	208	RB81419	BELT HOOK ASSY
RB443T	209	RB13260	SPECIFICATION LABEL (443USA)
RB443T	210	BB40724	BOLT 3X16 MEC